

HME

®

PRO850 Wireless Intercom

QUICK START GUIDE

- BATTERIES** If you purchased the rechargeable battery option, the batteries will need approximately three (3) hours of charging before use. Otherwise, place six (6) fresh AA alkaline batteries into the provided battery sled, observing correct polarity. Insert the battery or battery sled into the belt pac. Slide the battery door closed.
- ANTENNAS** Both the base and belt pacs are supplied with two antennas each, one for transmit and one for receive. Match the color code on each antenna with the color code on the base or belt pac connector. **NOTE:** No color code is considered black.
- POWER SUPPLIES** Use the power supply that is packaged in the same box with the battery charger and with the base, respectively. Connect the appropriate AC power cord to its power supply and plug it into an electrical outlet. Ensure the other power supply cords/connectors are completely inserted into their respective power jacks. Ensure the locking nut is securely tightened on the base **Power jack**.
- CONNECT HEADSETS** Insert headset connectors into the base and belt pacs until they snap into place.
- POWERING UP UNITS**
 - Base** - Press the top portion of the base **Power switch**. The power switch and display screen should light.
 - Belt pac** - Turn the **Master power/volume control** clockwise. The **PWR/BAT** indicator should light.
- The **WIRELESS** portion of the PRO850 is now ready for use with any standard **4-WIRE** system. **NOTE:** To return to this **System Setup**, follow the steps in 7 below, loading **File ▶8** instead of **File ▶9**.
- If the PRO850 is to be used with a standard **2-WIRE** system, see the display screen and follow these directions:
 - From **Config**, scroll down to **Files** (press **ENTER** button)
 - From **System Setup**, scroll down to **Load Settings** (press **ENTER** button)
 - From **Load Settings from File**, scroll down to **File ▶9** (press **ENTER** button)
 - Scroll right to **▶□ Load** (press **ENTER** button)
 - If successful, you will read **Success**.
- The **WIRELESS** portion of the PRO850 is now ready for use with any standard **2-WIRE** system. On the rear panel select **CLEAR-COM** or **RTS TW**.
- CONGRATULATIONS...YOU ARE NOW IN OPERATION!**