

Radio Active Designs Belt Pack – 4M



Volume for audio ch 1

Talk button for audio ch 1

Talk button for audio ch 2

Volume for audio ch 2



Power button, press and hold for 3 seconds to power on or off

Depending on how the belt pack is programmed the talk button can be trigger by either:

PTT: Push to Talk – active only while the button is pressed

ST Latch: Single Touch Latch – press once to latch the talk button on.



If the talk button turns Red during use, this means that the volume being received at the microphone is too loud. This belt pack will need to have it's mic gain level reduced.



Jim Montgomery | Senior AV Specialist
jim.montgomery@bhienergy.com

Radio Active Designs Belt Pack – 4M Mic Gain Adjustment



If the talk button turns Red during use, this means that the volume being received at the microphone is too loud. This belt pack will need to have it's mic gain level reduced.



These steps below will assist in adjusting the mic gain.


While the belt pack is powered on, tap the power button to enter the menu screen



Once in the menu screen, you will see MIC G on the bottom right. Pressing the #4 button will enter into the MIC Gain setting.



Adjust the Mic Gain by moving either volume control. A usual starting point is 18 ~ 20. Once the desired setting is made. Click on button #3 (Save)



Press Button #3 again to Exit.



Jim Montgomery | Senior AV Specialist
jim.montgomery@bhienergy.com